



AMMOCONTROL

LED Advisor


for 1911



PACKAGE CONTENT



AMMOCONTROL x1



Magazine x2
This accessory may not be available in your region.

TOOLS


*not included




Screwdriver

ASSEMBLY · GUN

Disassemble the original grips



Assemble **AMMOCONTROL** grips using original screws and washers




KNOW YOUR AMMOCONTROL

LED INDICATOR

AMBIENT LIGHT SENSOR


CHECK BUTTON

GRIP



LED Intensity is automatically adjusted depending on ambient light.

LED ACTIVATION EVENTS



Firing a gun or pressing the check button.

MONO-COLOUR 100-012

4/+4 rd. No Light

3 rd. Blinking Red (Slow)

2 rd. Blinking Red (Medium)

1 rd. Blinking Red (Fast)

0 rd. Continuous Red*

TRI-COLOUR 100-010

4/+4 rd. No Light



3 rd. Continuous Blue

2 rd. Continuous Green


1 rd. Continuous Red

0 rd. Blinking Red*

ASSEMBLY · MAGAZINE



Position of the blue parts on the spring.



Don't remove blue parts. They are necessary for correct device operation.