



AMMOCONTROL

Digital Counter for 1911



PACKAGE CONTENTS



AMMOCONTROL x1 Plastic support x1 Magazine x2

TOOLS

*not included




Screwdriver

This accessory may not be available in your region.


ASSEMBLY · GUN

Disassemble the original grips




Assemble the battery(LeftGrip)

Low battery: A point in Display Indicator.




Assemble plastic support

Put the plastic support between the gun and the left grip.




Assemble **AMMOCONTROL** grips

using original screws & washers



It's recommended remove the right thumb safety for better display view.


ASSEMBLY · MAGAZINE



Position of the blue parts on the spring.

Don't remove blue parts. They are necessary for correct device operation.

MAGAZINE CALIBRATION



THE CALIBRATION IS ONLY REQUIRED IF COUNT SEQUENCE IS INCORRECT.

1. ENTERING CALIBRATION MODE

Push total shot counter button (left) and reset button (inside grip).

2. MAGAZINE

Load 7 cartridges in the magazine.

3. GUN

Load a cartridge in the chamber.

4. FIRE THE GUN

Shoot holding check button, keeping an interval of 2 seconds between shots.

5. EXITING CALIBRATION MODE

- Automatically after last shot.
- After 15 seconds timeout counting from step 1.
- By pressing counter button until display shows 0.

*The device does NOT detect round housed in the chamber.**The device only works with original ACT-MAG. Important: Always observe the basic safety rules when handling firearms.

KNOW YOUR AMMOCONTROL


TOTAL SHOT COUNTER
BUTTON (LEFT)

DISPLAY INDICATOR

RESET BUTTON
(INSIDE GRIP)

AMBIENT
LIGHT SENSOR

CHECK BUTTON



DISPLAY ACTIVATION EVENTS


ACTIVATION

- Firing a gun.
- Pressing the check button.
- Pressing counter button to show the total number of shots fired.



COUNTER BUTTON


Press this button on left side of the grip to show the accumulated number of shots fired.



Push the check button to know the number* of cartridges in the magazine**.

Display intensity is automatically adjusted depending on ambient light.

DISPLAY EXAMPLE



→ 42 SHOTS



Reset shot counter: push reset button.

*The device does NOT detect round housed in the chamber.**The device only works with original ACT-MAG. Important: Always observe the basic safety rules when handling firearms.