AMMOCONTROL LED Advisor for Smith&Wesson®M&P Available for: 9 mm and .40

PACKAGE CONTENTS



CR 1632 Battery x1



Follower x2



AMMOCONTROL x1

ASSEMBLY - GUN

Disassemble the original backstrap



Assemble the battery (Left Side)



Assemble **AMMO**CONTROL backstrap




DISASSEMBLY · BATTERY

Disassemble the battery



ASSEMBLY · MAGAZINE

Disassemble the magazine*




Remove the original follower



Replace it with the

AMMOCONTROL follower



The system is ready to use



KNOW YOUR AMMOCONTROL



LED ACTIVATION EVENTS



Firing a gun or pressing the check button.

MONO-COLOUR 100-032/033 TRI-COLOUR 100-028/029

4/+4 rd. No Light

3 rd. Blinking Red (Slow)

2 rd. Blinking Red (Medium) 1 rd. Blinking Red (Fast)

0 rd. Continuous Red**

4/+4 rd. No Light

3 rd. Continuous Blue

2 rd. Continuous Green

1 rd. Continuous Red 0 rd. Blinking Red**

LED Intensity is automatically adjusted depending on ambient light.

*The device only works with original S&W magazine:**The device does NOT detect round housed in the chamber. Important: Always observe the basic safety rules when handling firearms.