

Important: Always observe the basic safety rules when handling firearms.

RADETEC 🌔

## **3.1 COUNT UP MODE**

Number of shots increases automatically.

#### SELECT MODE

Press either button for 1,5 seconds.



## **3.3 TOTAL SHOT COUNTER**

Records the number of shots fired from both modes.

Total Shot Counter mode can be only accessed when in Count Up mode.

#### SELECT MODE

Press both buttons for 3 seconds.



AUTOMATIC DISPLAY SEQUENCE



# **4.0 FEATURES**

2 separate modes Count up / Countdown

**Total Shot Counter** 

LCD Screen Only visible to the shooter

Interchangeable battery (CR1632) Low battery indicator

AmbidextrousBattery life20.000 shotsWeight < 25 gr.</td>Error rate < 0.1%</td>

## **3.2 COUNTDOWN MODE**

Number of shots decreases automatically.

#### SELECT MODE

Press either button for 1,5 seconds.




## **COUNTDOWN MODE: PROGRAMMING**

Enter the number of cartridges that you want to shoot and when shooting the numbers (LCD) will decrease.

#### SELECT MODE

Press both buttons for 3 seconds.



LEFT BUTTON subtracts shots.

RIGHT BUTTON adds shots.

Operational range temperature -20°C / 70°C

Storage range temperature -30°C / 80°C

MIL-STD-810G METHOD 504.1

IP53

COMPATIBLE MODELS Gen3 & Gen4

# 17 / 19 / 26 / 22 / 23

Other GLOCK models Gen3&4 could also be compatible. Stay tuned to our website for updates!

Important: Always observe the basic safety rules when handling firearms

CE FC 🕱 000263

www.radetec.com · info@radetec.com

